

**TIME DELAY OPENING INSTRUCTIONS**

For Model CS401 Lock

**TO ACTIVATE TIME DELAY LOCK**

1. TURN KEY CLOCKWISE UNTIL IT STOPS
2. TURN KEY BACK ANTI-CLOCKWISE UNTIL IT STOPS
3. WAIT TIME DELAY PERIOD 3 MINUTES
4. OPENING PERIOD BEGINS WHEN THE BUZZER SOUNDS OR THE RED LIGHT IS FLASHING
5. TURN KEY CLOCKWISE, HOLD KEY IN THAT POSITION, AND OPEN DOOR

**For Service contact CMI Safe Co. 02 9547 1488**